

FLYING FOX

The Flying Fox must be run by three adults over 18 years old. Two of those adults need to be physically fit & strong due to the physical nature of this activity. Note the Flying Fox cannot be used when raining (or tower is wet) or at night. The operators must not be prohibited from working with children.

Charges

- Self-run no charge. Condition for self-running the Flying Fox includes that the chosen operators
 be trained by the Site Manager to his/her satisfaction. All instructions must be obeyed. The trained
 operators must not change from their allocated trained position. The operators cannot be replaced
 by other operators unless trained by the Site Manager. Any variation to these conditions will result
 in the Site Manager prohibiting any use of the Flying Fox.
- Site run per hour charge see Pricelist (Minimum 2 hours). Conditions include that you provide two operators to aid in the running of the Flying Fox (one of which needs to be physically fit & strong). These operators are required to adhere to the instruction given to them by the site operator. NOTE: 7 days notice must be given for this option.

Conditions of Use

- To be operated by three (3) adults 18 years of age or over.
- Must have instruction and demonstration by Site Manager before use (ie. each new person who
 operates Flying Fox must have instruction from Site Manager).
- Site Manager to set up Flying Fox before each session.
- · Operators on tower must be harnessed to tower.
- Riders are to put on harness on bottom deck
- Operate using the following steps:
 - 1. Close front gate.
 - 2. Allow rider onto top deck and close back gate.
 - 3. Check harness
 - 4. Allow next rider up to top deck from lower deck. Close ladder gate. Max of 2 riders in waiting enclosure. No-one to wait on ladder.
 - 5. Put rider into cage and attach lap belt & tighten.
 - 6. Attach harness to overhead karabiner.
 - 7. Unclip ropes: Throw rope attached to platform over rail to ground. Roll up rope attached to cage and place beside rider, making sure none dangles from cage.
 - 8. Open and secure gate with cabin hook.
 - 9. Check Flying Fox travel path for personnel. Only one person is permitted on flight side of fence to assist with the demounting of rider. Do not proceed until travel path is clear.
 - 10. Pull cage back and release chain from hook.
 - 11. Release cage smoothly DO NOT PUSH.
 - 12. Rider is not to leave cage until it has come to a complete stop.
 - 13. After cage has been connected to rope, rider is to stand clear and release rope. Tower operator must not hold rope & allow pole to take jolt.
 - 14. Pull cage up and reconnect to chain.
 - 15. Start again at 1.

When session is complete:

- Lock gates.
- Lock up cage.
- Place ropes, belts, harnesses and key into bag and return to Site Manager.

